

Installation instructions for Cobra “FANGS” on the magnum A K series steering.

To install the FANGS on your magnum A K steering system, first be sure that the steering fins are set all the way down so that you can utilize the two bottom holes to mount the fang to the inside surface of the steering fin.

The fang should be installed with the flat side up and the round side down. This aligns the holes in the fang with the two bottom holes of the fins.

Install the button cap bolts from the outside and place the nylock nuts on the inside surface of the fang.

Do this process on both of your Magnum A K fins and you are finished with the install.



It's just that easy!